

# MAGNET PAINT - 磁力漆

Dear Customer (親愛的客人),



Below with the construction procedure of Magnet Paint or please click our Youtube Channel "MagpaintHK"  
以下為磁力漆的施工程序，亦可以到我們的 **Youtube** 官網參考施工短片 "magpainthk"

- 室溫大於 10 度 / 濕度不可大於 80% (乾透時間視乎實際環境而定)  
**Apply at room temp.: >10C / Humidity :Max. 80% (Local conditions may affect drying time)**
- 請用底油覆蓋牆身  
**Preparation seal surface with primer**
- 等底油乾透  
**Preparation let the primer dry**
- 一直攪拌直到油漆均勻  
**Stir until paint is homogeneous**
- 待徹底乾透約 4 小時再髹另一層 (乾透需時差異)  
**Let dry for at least 4 hours before applying next coat (Drying time may vary)**
- 再髹第二層如有需要再髹第三層  
**Apply second and, if necessary, third coat)**
- 如要跟平滑髹多一層，之後加一層薄灰再用砂紙輕輕磨擦  
**For a smoother surface apply an extra coat, thin putty treatment and sand lightly**
- 如想加強磁力請再髹多一層  
**For extra magnetic strength, apply an extra coat**

溫馨提示： 必須待每一層油漆徹底乾透，方可再髹另一層，否則後果可能出現差異

**Warm Reminder: Please make sure the coat dry thoroughly Before applying next coat**

Applying MagnetPaint with a short hair roller 磁力漆短毛油轆施工

<https://www.youtube.com/watch?v=jZ70ae2fzaQ>



Applying MagnetPaint with a long hair roller 磁力漆長毛油轆施工

<https://www.youtube.com/watch?v=hd3F4tHS4mc>

