

MAGNETPLASTER - 磁力石膏



Dear Customer (親愛的客人),

Below with the construction procedure of MagntPlaster or please click our Youtube Channel "MagpaintHK"
以下為磁力石膏的施工程序，亦可以到我們的 Youtube 官網參考施工短片 "magpainthk"

- 室溫大於 10 度 / 濕度不可大於 80% (乾透時間視乎實際環境而定)
Apply at room temp.: >10C / Humidity :Max. 80% (Local conditions may affect drying time)
- 請用底油覆蓋牆身
Preparation seal surface with primer
- 等底油乾透
Preparation let the primer dry
- 充分地攪拌
Stir thoroughly
- 檢查厚度, 第一層大約在 1-1.5mm
Check thickness, First coat between 1-1.5mm thick
- 等待乾透, 然後嘗試觸摸
Wait and let it' dry to the touch'
- 如果更平滑再髹多一層薄薄的
Apply final thin layer of MagnetPlaster for a smooth surface

Applying MagnetPlaster 磁力石膏施工

<https://www.youtube.com/watch?v=EKN2doT56DQ&t=51s>



www.magpaint.com.hk